



TH2 and TH4 Instructions

Using your Headset

1. TH2- Position headset in ear and adjust boom mic in front of mouth.
2. TH4- Clip elastic throat mic around neck ensuring the throat sensors are positioned on the front on either side of voice box and place the acoustic ear tube into ear.
3. Using either the velcro adhesive or clip position the tactical PTT on desired location on body.
4. Once the headset is comfortably placed in the ear, adjust the volume to a desired listening level.
5. To transmit, press the tactical PTT button.

TH2



TH4



Use and Care

1. Occasionally clean your headsets to extend the life. Use a soft damp cloth to clean the ear piece and cords. Do not use alcohol it can damage the plastic and make the cords brittle.
2. Take care of the cords- do not stretch or swing them. Avoid tightly coiling the cord around the radio when storing- this can cause breakage.
3. Do not immerse the headset in water. If the headset gets wet, dry it with a lint-free cloth.
4. Store your headset in a clean, dry place when not in use.

Warranty

Midland Radio Corporation will repair or replace, at its option without charge, any Midland headset which fails due to a defect in material or workmanship within 90 Days following the initial consumer purchase. This warranty does not apply to water damage or abuse.

Performance of any obligation under this warranty may be obtained by returning the warranted product, prepaid freight, along with proof of purchase to:

Midland Radio Corporation
Warranty Service Department
5900 Parretta Drive
Kansas City, MO 64120

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. Note :The above warranty applies only to merchandise purchased in the United States of America or any of the territories or possessions thereof, or from a U.S. Military exchange.

CHECK OUT THE OTHER GREAT MIDLAND PRODUCTS AT



GMRS
RADIOS



WEATHER
RADIOS



CITIZEN BAND
RADIOS



MARINE
RADIOS



EMERGENCY CRANK
RADIOS



MOTORCYCLE
HEADSETS